


Retighten exhaust system slip joints


All models

- Retighten slip joint bolts.




Single-pipe exhaust system (115.1 and 123.1)


- On models 115.0 and 123.023 with flange connection and spacing sleeves, tighten upper screws to 20 Nm (2 kpm) or lower screws to 15 Nm (1.5 kpm).



Single-pipe exhaust system (115.0 and 123.020/023)



Double-pipe exhaust system with catalyst



Double-pipe exhaust system

